

SENSOR CALIBRATION

To know when and how to calibrate:



Scan QR code

Or visit our YouTube channel

下 / ondilo



CALIBRATION







Choose the sensor to calibrate

Click on "calibrate" Follow the instructions

Caution:

Calibrate in a dry and clean area at room temperature.

Dry your hands and your ICO before handling it.

Single use solutions.



OndilO

ondilo.com



CALIBRATION

C.

SENSOR REPLACEMENT

Video tutorial: How to replace a sensor?





Scan QR code

Or visit our YouTube channel



Remove ICO from the water



Dry hands and ICO



Remove sensor cap

3

Use sensor tool



REPLACEMENT

To remove the sensor To place the new sensor





REPLACEMENT

(4)

back on ICO

