



INSTALLATION MANUAL


SOAKING TANK FOR FILTER CARTRIDGE

INSTALLATION AND EMPLOYMENT PRECAUTIONS


1. Position the tank on a flat surface and out of reach of children.
2. The tank must be closed with the lid when the descaling solution is inside.
3. Use gloves to handle the cartridge and descaling products.

MAINTENANCE OF THE FILTER CARTRIDGE

- 1 - Fill the tank (see attached table) with a cleaning solution respecting the stipulated dosages (1)
- 2 - Clean the cartridge with a jet of water (hose) or with a soft brush to remove larger particles
- 3 - Leave the cartridge submerged for at least 12 hours (2)
- 4 - Remove the cartridge and rinse thoroughly with a jet of water (hose)
- 5 - Empty and rinse the tank (3)



The lifespan of a cartridge is approximately 2 seasons, depending on its use and the frequency of cleaning.



<i>ref. tank</i>	<i>Weltico cartridge type</i>	<i>height in mm</i>	<i>cleaning liquid in liters</i>
62885	C5	746	12
62886	C6	871	15
62887	C7	996	18

Weltico

ACIS 15 rue des Marais

44310 St Philbert de Grand Lieu

client.acis@acis-france.com

- (1) We recommend using a cleaning solution for Weltico filters (e.g., ref. 63125 – Welclean)
- (2) Check the manual for immersion times in the solution used (8h for ref. 63125 – Welclean)
- (3) Check if current legislation allows the disposal of the used solution into the sewer.